

NAME- PRATIK RAJESH JADE

DIV- A

ROLL NO- A72

PHYSICS PRACTICAL

SR.NO	NAME OF EXPERIMENT
1	APPLICATION OF CRO
2	NEWTON'S RING (RADIUS)
3	NEWTON'S RING (R.I OF LIQUID)
4	NEWTON'S RING (WAVELENGTH OF LASER)
5	ENERGY BAND GAP OF SEMICONDUCTOR
6	I-V CHARACTERISTICS OF DIODE
7	PN JUNCTION DIODE AS RECTIFIERS
8	APPLICATION OF DIODE VOLTAGE REGULATION BY ZENER DIODE

Experiment no. 1

Name - Parik Jade

Roll no. - A72

Name of Experiment: Application of CRO


Date of Performance:

Aim - To measure amplitude of AC Voltage and determine unknown frequency using CRO.

Apparatus: Cathode Ray Oscilloscope (CRO), Function generator, Lissajous figure kit, connecting wires.

Diagram:

Amplitude Measurement:



Unknown Frequency:

unknown			Known
Frequency (f_y)	y CRO	x	Frequency (f_x)
Stepdown Transformer			Function Generator

Formula:-

$$\text{Unknown frequency} = F_y = \frac{n_x}{n_y} f_x$$

where, F_y = unknown frequency to transformer

Observation table:-

A] For measurement of frequency

Obs	i/p f_{eq} (Hz)	Peak to Peak Horizontal length (l)	Time Base (t)	Period. $T=t \times l$	Frequency $F=1/T$ (Hz)
A Signal wave					
1	400	2.6	1×10^{-3}	2.6×10^{-3}	3.846×10^{-4}
2	600	1.6	1×10^{-3}	1.6×10^{-3}	6.25×10^{-4}
3	800	1.2	1×10^{-3}	1.2×10^{-3}	8.33×10^{-4}
B Triangular wave					
1	400	2.6	1×10^{-3}	2.6	0.38
2	600	1.6	1×10^{-3}	1.6	0.625
3	800	1.2	1×10^{-3}	1.2	0.833
C Square wave					
1	400	2.6	1×10^{-3}	2.6	0.384
2	600	1.6	1×10^{-3}	1.6	0.625
3	800	1.2	1×10^{-3}	1.2	0.333

Sor.	Measurement of AC Voltage		Voltage (V/Div) ⁻ⁿ	Peak to Peak	Output Voltage
	i/P Voltage	Peak to Peak division (l)			
1	6.10	1.4	10	14	7
2	10.8	2.6	20	26	13
3	15.7	2	20	40	20

Unknown freqⁿ

Sr.	Known freq F_x (Hz)	No of loops horizontal discreetion nn	No of loops vertical discreetion ny	Unknown freq F_y (Hz)
1	200	1	1	200
2	300	2	1	600
3	400	3	2	600
4	600	4	3	600

$$\text{Avg. freq}^n = 550 \text{ Hz}$$

Formula -

$$\text{Unknown freq}^n (F_y) = \frac{nx}{ny} \times F(n)$$


Q1 Function of C.R.O

→ The cathode-ray oscilloscope (C.R.O) is a common laboratory instrument that provides accurate time & amplitude measurements of voltage signals over a wide range of frequencies. Its reliability, stability and ease of operation make it suitable as a general purpose laboratory. Its purpose is to generate the electron beam & control its intensity & focus. Between the electron gun & the fluorescent screen are two pairs of metal plates.

Q2 What ~~is~~ are different block of C.R.O

→ Cathode Ray oscilloscope (C.R.O) consists a set of blocks. These are vertical amplifier, delay line, trigger circuit, time base generator, horizontal amplifier, cathode Ray tube (CRT), power supply.

Q3 Block diagram of C.R.O.



Experiment no. 2

Name of Experiment - Application of Interference
Date

Aim - Determination of radius of curvature of plano-concave lens using Newton's ring setup.


Apparatus : ① Newton rings apparatus consisting of

- a. Plano-concave lens
- b. Optically flat glass plate
- c. Beam splitter
- d. T-Type traveling microscope with scale with L.C = 0.001 cm

② Monochromatic source of light of known wavelength (e.g. sodium)

③ Reading lamp & reading lens.

Diagram :



Formula:

$$R = \frac{[D_m^2 - D_n^2]}{4(m-n)} \lambda$$

Where

R = Radius of curvature of planoconvex lens

D_m = Diameter of mth dark ring

D_n = Diameter of nth dark ring.

Newton Ring to final Radius:

No of Ring	Microscopic Reading Left side (a) cm	Microscopic Reading Right side (l) cm	Diameter D = (a-l) cm	D ² in cm.
1	9.989	10.021	0.032	0.001
3	9.986	10.037	0.053	0.003
4	9.973	10.046	0.073	0.005
6	9.937	10.086	0.149	0.022
7	9.863	10.118	0.235	0.055
8	9.871	10.127	0.256	0.066
9	9.861	10.075	0.214	0.046

Formula $R = \frac{D_n^2 - D_m^2}{4 \rho \lambda}$

$$\rho = 10, n = 1$$

$$R = \frac{0.046 - 0.001}{4 \times 10 \times 5890 \times 10^{-8}}$$

$$R = 0.0459$$

$$R \approx 13 \text{ cm}$$

Q1 How Newton's Ring forms?

Newton's rings are formed as result of interference between the light waves reflected from the top & bottom surface of the air film formed between lens & glass sheet.

The phenomenon of the formation of Newton's ring can be explained on the basis of wave theory of light. An air film of varying thickness is formed between lens & the glass sheet.

Q2 Why fringes are circular in Newton's ring exp.

→ The path difference between the reflected ray & incident ray depends upon the thickness of air gap between lens & the base. As the lens is symmetric along its axis the thickness is constant along circumference of a ring of given radius. Hence Newton's rings are circular.

Q3 What is interference? Define its types.

→ The effect of combination of two or more wave trains moving on intersecting or coincident paths. The effect is that of addition of the amplitudes of the individual waves at each point affected by more than one wave.

There are two types of interference

- ① Constructive interference
- ② Destructive interference.

Experiment 3


Name of exp - Application of interference
 Date

Aim - Determination of refractive index using Newton's ring set up.

Apparatus - (1) Newton's ring apparatus consisting of


- a. Plano-concave lens
- b. Optically flat glass plate.
- c. Beam splitter
- d. T type travelling microscope with scale with $LC = 0.001\text{cm}$
- (2) Monochromatic source of light at known wavelength (e.g. Sodium)
- (3) Reading lamp & reading lens
- (4) Liquid.

Diagram :-




Experimental set up for observing Newton's rings.

liquid



The Ray diagram for Newton's Rings



Newton's Rings

Formula.

$$R = \frac{[(D_m^2 - D_n^2)]}{[4(m-n)\lambda]}$$

Where

R = Radius of curvature of planoconvex lens

D_m = Diameter of m^{th} dark rings

D_n = Diameter of n^{th} dark rings

λ = wavelength

μ = Refractive index of the medium in between planoconvex lens & glass plate

$$\mu = \frac{(D_{m+p}^2 - D_n^2)_{\text{air}}}{(D_{m+p}^2 - D_n^2)_{\text{liquid}}}$$

Observation Table.

I.C. of travelling Microscope (Air)
= 0.001 cm.

(Liquid)

No. of Ring	Micrometric Reading Left (a)	Micrometric Reading Right (b)	Diameter $D = (a-b) \text{ cm}$	D^2 cm	2^{nd} Ring Difference
1	9.912	10.107	0.195	0.038	
3	9.862	10.251	0.389	0.151	
4	9.838	10.295	0.457	0.209	0.151
6	9.771	10.296	0.525	0.276	-0.030
7	9.732	10.340	0.608	0.370	
8g	9.586	10.429	0.843	0.711	0.123

(Air)

No of Ring	Microscopic Reading		Diameter $D = (a-b) \text{ cm}$	D^2 cm	2^{nd} Ring Diameter
	Left	Right			
1	9.959	10.021	0.032	0.001	
3	9.984	10.037	0.053	0.003	0.003
9	9.973	10.046	0.073	0.005	<u>-0.001</u>
6	9.937	10.086	0.149	0.022	0.002
7	9.883	10.118	0.235	0.055	
8	9.871	10.127	0.256	0.066	
9	9.861	10.075	0.214	0.046	

When $R = \text{Same}$

$$R = \frac{D_m^2 - D_n^2}{4(m-n)\lambda} \text{ air}$$

$$R = \frac{D_m^2 - D_n^2}{4(m-n)} \text{ liquid.}$$

By Formula

$$\mu = R \cdot I \text{ of liquid}$$

$$\mu = \frac{(D_m^2 - D_n^2) \text{ air}}{(D_m^2 - D_n^2) \text{ liquid.}}$$

$$= \frac{0.113}{0.002}$$

$$= 0.05$$

Result: $\mu = 0.05$

RI = given liquid.

Name of experiment - 4

Newton Ring experiment for laser light wavelength.

Aim - Newton's Ring Experiment for Laser Light wavelength.


Formula

$$\lambda = \frac{D_{m+p} - D_m}{4 p R}$$


where D_{m+p} is the diameter of the $(m+p)^{\text{th}}$ dark ring.

D_m = Diameter of the m^{th} ring.

Diagram



Result - Wave length of light from the given source is found to be 6700 Å



VARIABLES

Select Medium:

Air

Light Source

Red Light

LIGHT OFF

Radius Of Lense : 65 cm



Microscope Position



Microscope Focus : 7.5 cm



RESET

 Show result

RESULT

Wavelength : 6700 Å

Experiment - 5

Energy Band Gap of Semiconductor.

Aim - To determine energy band gap of the semiconductor.

Theory:- In the reverse bias, the saturated value of reverse current for a PN junction diode is given by
 $I_s = A \cdot T^{3/2} e^{-\frac{qg}{kT}} \quad \dots \text{--- } ①$

Where

A = constant term

I_s = saturated current in micro ampere

T = Temperature of junction diode in Kelvin

qg = band gap in eV

k = ~~band gap in eV~~ Boltzmann constant in eV per Kelvin

for small changes in Temperature where $\log T$ can be treated as constant relation can be written as


$$\log_{10} I_s = \text{constant} - 5.04 \cdot \log_{10} T \quad \dots \text{--- } ②$$

Graph between $10^3/T$ as abscissa & $\log_{10} I_s$ as ordinate will be a straight line having a slope $-5.04 qg$

Hence band gap

Eg:- Slope of line 15.04

Diagram



Result :- Energy band gap $E_g = \frac{0.746}{5.04}$


$$= 0.148$$

Observed energy band gap is - 0.148

ENERGY BAND GAP SIMULATION

DISABLE POWER	
Place Container	
P-N Diode	Battery
Ammeter	Voltmeter
Point	Connect
Place Thermometer	
Undo	Redo
Reset	
Message	

```
>>Undo Done..
```



04 Selected Voltage is **04 Volt**

Slide to choose Temperature
0 100
Selected Temperature is **20 °C**

Get Reverse Saturation Current

Respected value is **5.346 μA**

FORMULAS


$$I_s = A * T^{3/2} e^{-\frac{E_g}{kT}}$$

$$\log_{10} I_s = \text{Constant} - 5.04 * E_g * 10^3 * \frac{1}{T}$$

$$E_g = \frac{\text{Slope of the line}}{5.04}$$

TABLE : OBSERVATIONS

S.No.	Temperature(°C)	Current I_s (μA)	Temperature(°K)	$10^3/T$	$\log_{10} I_s$
01	90	40.711	363	2.75	1.610
02	85	36.155	358	2.79	1.558
03	75	28.226	348	2.87	1.451
04	60	18.934	333	3.00	1.277
05	55	16.441	328	3.05	1.216
06	45	12.232	318	3.14	1.087
07	30	7.568	303	3.30	0.879
08	20	5.346	293	3.41	0.728



NOTE : Enter value of X coordinate and Y coordinate seperated with comma(,)

2.7548,1.6097

3.4129,0.7280

Calculated Slope is **-0.746**

NOTE : Enter value of Slope calculated above in the below box

Energy Band Gap (E_g) = /5.04

Observed Energy Band Gap is **-0.148**

Experiment - 6

Characteristics of Diode

Aim - VI characteristics of a Diode

Objectives


- (i) Explain the structure of P.N Junction diode
- (ii) Explain the function of a P.N junction diode.

(i) Structure of P.N Junction diode.


The diode is a device formed from a junction of n type and p-type semiconductor material the lead connected to the p type material is called the anode & the lead connected to n type material is called cathode. In general the cathode of a diode is marked by a solid line on the diode.

(ii) Function of P.N junction diode.

Allows current flow when the voltage applied in a forward bias polarity & allows current flow when voltage is applied in the reverse bias polarity. This is why a diode can function as a one way valve for electric circuit.



P.N junction diode in forward bias.



P.N junction diode in
Reverse bias.




INSTRUCTION

EXPERIMENTAL TABLE

Serial No.	Forward Voltage(Volt)	Forward Current(mAmp)
1	0.570	1.66
2	0.582	3.65
3	0.593	6.31
4	0.599	8.30
5	0.606	11.6

Forward Bias Silicon Diode



CONTROLS

Select Diode: 1N4148 V_F : 0.5
 DC volt : Volt
 Resistance : ohms


Add to Table Plot Clear

Print It

Check for Reverse Bias

GRAPH PLOT

V-I Plot



Copyright © 2011 Indian Institute of Technology Kharagpur, [Licensing Terms](#)



An MoE Govt of India Initiative




INSTRUCTION

EXPERIMENTAL TABLE

Serial No.	Reverse Voltage(Volt)	Reverse Current(μ Amp)
1	6.92	0.100
2	9.41	0.100
3	12.2	0.100
4	15.5	0.100
5	19.8	0.100
6	26.0	0.100

Reverse Bias – Silicon Diode




CONTROLS

Select Diode: Choose Diode V_R DC volt : VoltResistance : ohms[Add to Table](#)[Plot](#)[Clear](#)[Print It](#)

GRAPH PLOT

V-I Plot



Copyright © 2011 Indian Institute of
Technology Kharagpur, [Licensing](#)
[Terms](#)

Experiment - 7

Aim - To study the characteristics & work function of half wave rectifier & full wave rectifier

Equipment: Breadboard, diodes, power supply, connecting wires, multimeter, etc.

Theory:

- (i) In half wave rectification, either the positive or negative half of AC wave is passed, while the other half is blocked.
- (ii) A full-wave rectifier converts the whole of the input waveform to one of constant polarity (positive or negative) at its output.
- (iii) While half wave & full wave rectifiers deliver a form of DC output.
- (iv) In order to produce steady DC from a rectified AC supply, a filter circuit is required. In its simplest form this is achieved by shunting the resistor with a capacitor.
- (v) Full wave rectification rectifies the negative components of the input voltage to a positive voltage, then converts it into DC utilizing a diode bridge configuration.
- (vi) In contrast, half wave rectification removes just the negative voltage components using a single diode before converting to DC.

Procedure:-

- (i) Design the circuit as per the diagram on bread board.
- (ii) Connect diodes, power supply, wires, multimeters, etc as per the circuit
- (iii) Note down the graphical information after observing the wave formed

Conclusion:-



- (i) Half & full wave rectifiers are used to converts AC into DC Voltage
- (ii) This is the primary function of the rectifier in industrial applications.
- (iii) From the graph.
 - (A) In half wave rectifier,
 $V = 549.52 \text{ mV}$
 $i = -549.52 \text{ A}$
 - (B) In full wave rectifier
 $V = -9.0146 \text{ V}$
 $i = -9.0146 \text{ nA}$

Int...



Paused

Single





Int...



Paused

Auto



Experiment - 8

Aim - To study the characteristics of zener diode & its work function

Equipment - Breadboard, zener diode, power supply, multimeter, connecting wires, etc.

Theory : (i) The zener diode mainly operates in reverse biased condition.

- (ii) We use zener diodes for voltage regulation & voltage stabilisation. They provide a low cost and no frill method for voltage regulation.
- (iii) The critical parameter of this type of diodes is the zener breakdown voltage
- (iv) The zener breakdown voltage is a minimum reverse biased voltage below which the diode blocks the biased voltage below which the diode blocks the reverse current through it and above which it causes a significant amount of reverse bias current to flow through it
- (v) Once, the reverse voltage reaches the zener breakdown voltage the voltage across the device remains constant at that level.
- (vi) Hence, we can use zener diode for voltage regulation.

Procedure

- (i) Design the circuit as per the diagram on bread board.
- (ii) Connect the power supply as per the circuit diagram
- (iii) Observe the wave formed.

Conclusion:-

- (i) The zener diode, with its accurate & specific reverse breakdown voltage allows for a simple, inexpensive voltage regulator.
- (ii) The low power rating of standard zener diodes and resistors make this solution impractical for high power devices
- (iii) From the graph.

(A) In forward zener diode

$$V = 4.4225V$$

$$i = 4.4225 \text{ mA}$$

(B) In reversed zener diode



$$V = 105.15 \text{ mV}$$

$$i = 105.15 \mu\text{A}$$

Int...

No trigger

None




Zener diode (reverse)

Int...


No trigger

None



1ms/div

v 4.4225V
i -4.4225mA



Zener diode (forward)